Pioneer sound.vision.soul

CDJ-800MK2 Software Update

Applicable Models: CDJ-800MK2

To confirm the CDJ-800MK2 system version

1. Turn power ON.

- 2. Hold the RELOOP/EXIT button depressed for 10 seconds.
 - * The system version will appear in the display. [Display example] Ver. 2.10
 - * To return the CDJ-800MK2 to normal operation, turn the power \overline{OFF} and then ON again.

Program Update Procedures

- 1. Confirm that unit power is OFF and no disc is loaded. In this condition, hold the TIME MODE/AUTO CUE and AUTO BEAT LOOP2 buttons depressed simultaneously, and turn power ON.
- 2. When "DOWNLOAD" appears in the display remove your fingers from the TIME MODE/AUTO CUE button and AUTO BEAT LOOP2 button.
- 3. Insert the program update disc.
 - * The display will show the "DOWNLOAD" scrolling menu.
 - * Do not turn power OFF while the update process is continuing.
 - * Update will be completed in about 1 minute.
 - * When the update is finished, the "COMPLETE" message will appear and the program update disc will be ejected.
- 4. Remove the program update disc and turn power OFF.

This completes the update procedure.

NOTES

- ◆ Follow the above procedure closely to perform update.
- Never not turn off or disconnect power, or remove a disc while update is in progress.
- ◆ If you have any questions regarding this procedure, consult the Pioneer service department.
- ◆ If "ERROR" appears in the display, stop the operation, turn off the power, and consult the Pioneer service department.